PF8

Desktop Printer

Accessory Guide

Cables

Item Name	Part Numbers	Description
Serial Cable	1-974024-018	The RS232 serial Cable 1,8m (DB9F - DB9M) can be used to communicate with the printer and to upgrade the printer.
USB Cable	321-576-004	The PF8 can use the USB -A to USB-B, 2 meter cable to connect to PrintSet or other software. Note: the USB cable ships standard with each printer.
Parallel Cable	1-974022-018	The IEEE 1284 Parallel cable is 1.8m long. Typically used on legacy computer systems. Note: the Parallel cable ships standard with each PF8t printer only.
Stripper Module	151-000042-902 (PF8d) 151-000041-902 (PF8t)	The PF8 Stripper Module strips the backing off of a label. Note: there are two part numbers, one for the PF8d and one for the PF8t.
Cutter Module	151-000044-902	The PF8 Cutter Module cuts continious labels to length.
Real Time Clock Compact Flash	151-000045-902 (PF8t only, RTC is standard on PF8d)	Combined Real-time Clock (RTC) and 1GB Compact Flash (CF) expansion module for PF8t. Note: PF8d comes standard with RTC.



PF8

Desktop Printer

Accessory Guide

Power

Item Name	Part Numbers	Description
Power Cords	226-00001-200 226-000010-100 226-000011-400 226-000015-600	AC Power Cord US RoHS AC Power Cord for Europe RoHS AC Power Cord for UK RoHS AC Power Cord for China RoHS

Power Supply



1-092363-00

Universal Power Suppply (100-240V). Note: the power supply ships standard with each printer.

Included in the Box

Printer Description

PF8t



Neo includos Ouisk Str

Also includes Quick Start CD No Power cord

PF8d



No Power cord

Intermec°

Lopyright © 2010 Intermec Technologies Corporation. All rights reserved. Intermec is a registered trademark of Interme Technologies Corporation. All other trademarks are the property of their respective owners. Printed in the U.S.A. 612041-014 04/10